

Survivor 7in1 Torch Powerbank 10000 Quick guide

421-09





www.sandberg.world

Survivor 7in1 Torch Powerbank 10000 Item no. 421-09 Made in China Sandberg A/S: Bregneroedvej 133D, 3460 Birkeroed, Denmark ww.sandberg.world



Support

http://helpdesk.sandberg.world



There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty



For information on handling electronic waste, ee www.sandberg.world/weee



NOTE: For optimal battery performance, we recommend fully discharging and recharging the torch at least once every three months.




Dverview Button LEDs for battery status Side torch USB-C Input USB-A Output

Accessories:




Charge Torch






Charge device



Torch







Side torch



Double press to turn on the light (high).





Press once more for low light.





Press once more for red light.





Press once more for red flashing light.





Press once more to turn off the light.



Emergency tool



