



Wireless Headset ANC+ENC


Quick guide







Quick guide




126-44

"Connected"



Product overview



1. Microphone







3.



7. USB-C port for charging and wired connection $% \left(1\right) =\left(1\right) \left(1\right$

8. LED indicator



Quick guide

Button	Wired mode with USB cable		Bluetooth mode with ENC/ANC		
	Function	Operation	Function	Operation	Note
(b)		-	Power on/off	Press and hold for 2 seconds	
	Play/pause music	Press once	Play/pause music	Press once	Only for music playing
		-	Pick up/Hang up a call	Press once	-
	-	-	Redial last number	Press twice	-
	-	-	Reject a call	Press and hold for 2 seconds	-
	-		Unpairing	Press three times	Unpair your bluetooth headset by simply press this button three times in a row, then you can pair to a new smart device
•	ANC on/off	Press and hold for 2 seconds	ANC on/off	Press and hold for 2 seconds	
•	Microphone mute on/off	Press once	Microphone mute on/off	Press once	-
•	Volume up	Press once	Volume up	Press once	-
	Next Track	Press and hold for 2 seconds	Next Track	Press and hold for 2 seconds	-
-	Volume down	Press once	Volume down	Press once	-
	Previous Track	Press and hold for 2 seconds	Previous Track	Press and hold for 2 seconds	-







LED and Voice indicator overview

Power on	The indicator light flashes red and blue, and the voice prompt says "power on".			
Power off	The indicator light turns off, and the voice prompt says "power off".			
Bluetooth connected	The indicator light flashes blue, and the voice prompt says "Bluetooth mode".			
Bluetooth disconnected	The indicator light flashes red and blue, and the voice prompt says "disconnected".			
Charging the headphones	The indicator light will be red while charging and turns off when the headphones are fully charged.			
Microphone mute on	The voice prompt says "mute on".			
Mocrophone mute off	The voice prompt says "mute off".			
Low battery	The voice prompt "low battery" is played every 30 seconds when battery is low.			
ANC on	The indicator light turns solid green.			
Power saving mode	The headset will automatically turn off after 5 minutes of inactivity.			
Connected with USB cable	The voice prompt says "power on".			









Manufacturer: Sandberg A/S

Address: Bregneroedvei 133D, 3460 Birkeroed, Denmark

Product description: Wireless headset with charging dock

Product name/Type no: Sandberg Wireless Headset ANC+ENC / 126-44

We declare under our sole responsibility that the products, to which this declaration relates, are in conformity with the Council Directives on the approximation of the laws of the EEC Member States relating to the following:

Directives

CE letter of

conformity

EMC Directive 2014/30/EU RED Directive 2014/53/EU

RoHS Directive 2011/65/EU with amendment (EU)2015/863

And standards

ETSI EN 300 328 V2.2.2 (2019-07)

ETSI EN 301 489-1 V2.2.3 (2019-11)

EN 301 489-17 V3.2.4 (2020-09)

EN 55032:2015+A1:2020

EN 55035:2017+A11:2020

EN IEC 61000-3-2:2019+A1:2021

EN 61000-3-3:2013+A2:2021

EN 62479:2010

EN 50663:2017

EN IEC 62368-1:2020+A11:2020

IEC 62321-3-1:2013

IEC 62321-4:2017 IEC62321-5:2013

IEC62321-6:2015

IEC62321-7-1:2015

IEC62321-7-2:2017 IEC62321-8-2017

Date: 27th October 2023 Location: Birkeroed, Denmark

Name: Anders Petersen





http://helpdesk.sandberg.world

Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty



🔼 Sandberg®

Item no. 126-44

Wireless Headset ANC+ENC

Sandberg A/S www.sandberg.world Breaneroedvei 133D.

3460 Birkeroed. Denmark







NOTE: For optimal battery performance, we recommend fully discharging and recharging the power bank at least once every three months.



For information on handling electronic waste, see www.sandberg.world/weee