

Car Jumpstarter Powerbank 10000

Quick guide










Product overview




- 1. LED display screen
- 2. Power button
- 3. USB-C input
- 4. USB-A output

- 5. LED light button
- 6. 12V car start output port
- 7. LED light



Charge Powerbank





LED status display

ŧ



Jumpstarter function

Disclaimer:


Only designed for cars with 12V systems. Gasoline max 12V/4.0T and Diesel max 12V/3.0T.

After a jumpstart attempt, if failed, please wait min. 1 minute before trying again.


If the engine cannot be started after 3 attempts. try to find the problem elsewhere on the engine.

Jumpstarter procedure:


1. Turn on powerbank




- Connect clamps to car battery Important to follow this:
 - 1. RED to RED (positive)
 - 2. BLACK to BLACK (negative/chassis)




5. Remove cable from the power bank




2. Connect jumpstarter cable to power bank interface



4. Try to start the engine Turn key / press start button



Remove clamps from the car battery






Jumper Clamp Indicator Instruction

Item	Technical parameters	Instruction
Input high voltage protection	16.8V±0.5V	The red light is always on, the green light is off, and the buzzer does not sound.
Work instruction	Support	When working normally, the green light is always on, the red light is off, and the buzzer beeps once.
Reverse connection protection	Support	The red/black clip of the wire clip is eversely connected to the car battery (battery voltage ≥0.8V), the red light is always on, the green light is off, and the buzzer sounds at short intervals.
Short circuit protection	Support	When the red and black clips are short-circuited, no sparks, no damage, the red light is always on, the green light is off the buzzer 1 long and 2 short beeps.
Start timeout protectior	90S±10%	The red light is always on, the green light is always on, and the buzzer does not sound.
Connect to the high voltage alarm	Support	The clip is mistakenly connected to battery that is >16V, the red light is always on, the green light is off, and the buzzer sounds slowly and shortly.
Automatic anti-virtual electricity function	Support	When the car battery voltage is higher than the Starter battery voltage, the output is automatically turned off and the green light is on, at this time, it can be ignited normally. If the car battery voltage drops and is lower than the starter battery voltage during the ignition process, the smart clip will automatically turn on the output to complete the startup process.



Charge devices







Flashlight procedure




 Short press to turn on flashlight



3. Short press once more for SOS



2. Short press once more for caution light



 Short press to turn off flashlight





http://helpdesk.sandberg.world

Warranty

There is a five-year warranty on your Sandberg product.

Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty



Jumpstarter Powerbank 10000

tem no 420-0

Battery: Lithium Polymer 10000

LICE C Input: 5\/-24 or 0\/-24 (10\/) Mov

IISR-A Output: 5V=3A 0V=2A 12V=1.5A (18W

Clamp Rated Output: 12V DC 1000A

Clamp Book Output: 12V DC 2000A

Product weight: 550c

Sandberg A/S

Bregneroedvei 133D. 3460 Birkeroed, Denmar



NOTE: For optimal battery performance, we recommend fully discharging and recharging the power bank at least once every three months.

