

Powerbank USB-C PD 127W 40000

Quick guide


420-63B



www.sandberg.world




Charge Powerbank



2



Charge devices



NOTE: The powerbank doesn't support charging of low power consuming devices such as earphones. The powerbank will turn off automatically, and the device will not be charged.

3





http://helpdesk.sandberg.world

Warranty

There is a five-year warranty on your Sandberg product.

Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty



Powerbank USB-C PD 127W 40000	Item no. 420-63B	www.sandberg.wo
Capacity: 40000 mAh / 148 Wh		Sandberg A/S
USB-C input: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/5A (100W max)		Bregneroedvej 133
USB-C output 1: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/5A (100W max)		3460 Birkeroed, De
USB-C output 2 (simultaneous with C1 and solo): 5V/3A, 9V/3A, 12V/2.25A (27W)		LIKE
USB-A output (solo): 5V/4.5A, 9V/2A, 12V/1.5A (22.5W)		SHE.
Total power C1+C2: 100W+27W		CHI
Total power C1+C2+A: 100W+15W (C2+A sharing 15W)	Product weight: 765g	Mada in Ohio

NOTE: For optimal battery performance, we recommend fully discharging and recharging the power bank at least once every three months.

